



CT24RT22

Single DIN Fitting Kit for Renault Vehicles



IN THE KIT

- Double DIN Fascia Panel
- Frame Bracket
- Single DIN Pocket

APPLICATION

Note: Application data is subject to change at any time

Renault Master	2020 >
Nissan NV400	2020 >
Opel/Vauxhall Movano	2020 >

Note: for vehicles without OEM touchscreen displays.

FEATURES

- Allows for the installation of a single/double DIN aftermarket stereo
- Includes mounting brackets and fitting accessories
- Finished in matt black to match vehicle dashboard

DISCLAIMER

The information provided in this document is subject to change without notice due to manufacturer changes and/or improvements to the product/s. This instruction manual is based on documented data and research. The manufacturer of this product cannot be held responsible for any changes made to the vehicle by the manufacturer or damages that may occur through the installation of this product in accordance with the steps outlined herein.

PRIOR TO INSTALLATION

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure that the correct tools are used during the installation to avoid damage to the vehicle or product. **Connects2 can not be held responsible for the installation of this product.**

INSTALLATION GUIDE

DASH DISASSEMBLY

1.



Begin by using a panel removal tool to pry away the main fascia trim that surrounds the main radio, this trim includes the top pocket.

2.



With the trim out of the way, undo the 4x screws that surround the main head unit and remove it whilst disconnecting all of the wiring.

FASCIA ASSEMBLY

3.



Insert the pocket into the desired section of the fascia, normally this would be the bottom section.

When in place, take the two locator clips and slide them onto the locator tracks (*see the image*) and screw them down to lock the pocket into place.

INSTALLATION GUIDE

DASH ASSEMBLY

4.



Using the 4x pre-existing screws from the main head unit, screw the frame bracket into place.

5.



Insert the radio cage into the empty portion of the fascia and install the fascia onto the dashboard. You can then fully connect the radio.

Once fully connected, insert the radio into place to complete the installation.

NOTES
